



URGENT TECHNICAL INFORMATION ***The Lars Larson Show is changing satellite parameters!!!***

Effective March 30, 2009, "The Lars Larson Show" is moving to the Dial Global Satellite System. This uplink is fully compatible with every Starguide receiver and software version. To move to this new uplink, please follow the instructions below. If you have technical or operational concerns, please contact Lars Larson's team directly at 503-417-7630 Matt Trom or Eric Wilson.

Starguide Reprogramming:

From the front panel, <RIGHT ARROW> to CARRIER MENU and press <ENTER>

Press <RIGHT ARROW> to MANUAL ENTRY and press <ENTER>

Press <ENTER> to get to frequency...

Enter the following frequency (including zeros) 1124600 and press <ENTER>

Press <ENTER> to data rate...

Enter the following data rate (including zeros) 2048000 and press <ENTER>

Press <ENTER> to VIT (Starguide III Only) it should be set to 2/3

Press the <UP ARROW> until you reach the home screen

From the front panel, <RIGHT ARROW> to PORT MENU and press <ENTER>

Press <RIGHT ARROW> to the port where your audio card is installed press <ENTER>

You should see "PORT X PROVIDER", press <ENTER>

<RIGHT ARROW> to DG DENVER and press <ENTER>

<RIGHT ARROW> to SERVICE and press ENTER

<RIGHT ARROW> to Dial Global and press ENTER

Once you have completed this process, call Dial Global Network Operations at 720-873-5177 to authorize your receiver. You will need to provide your call letters, street address, studio hotline and contact name.

Audio will be available on both Left and Right Outputs of your Starguide Card:

Pin			Pin
1	Left Audio +	Right Audio +	5
6	Left Audio -	Right Audio -	9
4	Ground	Ground	7

The relays will trigger on relays 1&3 for your local Stop set Start, 2&4 for the Station ID

This wiring is compatible with any previous Starguide configuration you utilized for the show.